

**Installation:** Position hinge so one side is on door and the other on the frame and the capstan is on top. Mark and drill starter holes. Attach with screws. To set spring tension, use wrench in top of pin or insert adjusting rod into hole of capstan. Turn clockwise and insert stop pin in hole of capstan to maintain tension.

**Use:** On lightweight gates and storm doors.

**Installation :** Placer un côté de la charnière sur la porte et l'autre sur le cadre. Marquer et pré-percer les trous. Fixer avec les vis.

**Utilisation :** Pour barrières légères et portes moustiquaires.

**Instalación:** Colocar la bisagra de manera que un lado quede en la puerta y el otro en el marco. Marcar y perforar agujeros guía. Fijar con tornillos.

**Usage:** En puertas de peso ligero y puertas de tormenta.